

TERMINAL:

Default terminal parameters:

Baud rate: 115200
Data-bits: 8
Parity: none
Stop-bit: 1
Terminal type: VT102

```
ATMEL DataFlash LOADER VER 1.05 Aug 15 2006 18:34:34
*-----*
DataFlash[4.24 Mhz]:AT45DB642
Nb pages: 008192
Page Size: 001056
Size=08650752 bytes
Logical address: 0xC0000000
*-----*
1: Program Dataflashboot.bin at ...[C0000000]
2: Program U-Boot.bin at .....[C0008400]
3: Load UBOOT from [C0008400] to [0x23f00000]
4: Program Dataflash at .....[addr]
5: Read Memory .....[addr]
6: Erase Dataflash containing .....[addr]
*-----*
er: 6 c0000000
```

TECHBASE CO. LTD.

Poland,
Gdansk, st. Pana Tadeusza 14
80-123

Phone: (48)58 345 39 20
Fax: (48) 58 345 39 15
E-mail: info@techbase.eu

NPE SERVICE TOOL

Service kit to program and fix
NPE Embedded Computer



 **TECHBASE**


Instruction

COPYRIGHT & TRADEMARKS

Specifications are subjected to change without notice.

No part of the specifications may be reproduced in any form by any means or used to make any derivative such as translation, transformation, or adaptation without permission from TechBase Co., LTD.

Package Contents:



- ⇒ Converter USB to RS232(TTL-3.3V)
- ⇒ Flat cable DB9-Service connector
- ⇒ CD with drivers

Note:

Make sure that the package contains the above items. If any of listed items are damaged or missing, please contact with your Key Accountant Manager.

INSTRUCTION

USB Converter:

Detailed instruction of USB Converter installation you could found in ATC-830 documentation. Drivers for converter you could found on attached CD.



Terminal:

<http://www.atc-converters.eu/atc-830-p-5350.html>

You could use custom terminal software to display received information from device.

For Windows system it is recommended:

- [PC Comm terminal emulator](#)
- [Putty](#)
- [HyperTerminal](#)

For Linux system:


- [Terminator](#)

Note:

It is very important to connect device using service port in properly order. In other case, device or converter could be hanged or broken.

Connection:

I. Connect USB-RS232 converter with DB9-service connector



II. Remove front panel




A. Open Plexiglas shield



B. Take-off plastic panel.

III. Connect flat-cable to red-socket



First-pin-indicator should be closer to three led's.

IV. Connect converter to PC.