

ICOP-6052VF

**Embedded 386SX PC/104 All-in-One CPU
Module Series**

User's Manual

(Version 1.0)

Copyright Notice

This document is copyrighted, 2003 by ICOP Technology Inc. All rights are reserved. The information in the manual is subject to change without notice in order to improving products.

No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of the manufacturer.

ICOP Technology Inc. assumes no responsibility for any inaccuracies that may be contained in this document. ICOP Technology Inc. makes no commitment to update or to keep current the information contained in this manual.

©Copyright 2003 by ICOP Technology Inc.
All rights reserved. Ver.1.0 ,
Printed in Taiwan

Trademarks Acknowledgments

All brand names and trademarks are the properties and registered brands of their respective owners.

Table of Contents

CHAPTER 0	1	STARTUP	1
0.1	Packing List		1
0.2	Specifications		2
0.3	Component Location		3
CHAPTER 1	1	INTRODUCTION	4
1.1	Features		4
1.2	Specifications		5
1.3	VGA Interface		7
1.4	DiskOnChip 2000 Flash Disk		8
CHAPTER 2	2	INSTALLATION	9
2.1	Jumper Settings		9
2.2	Connectors		11
2.3	DiskOnChip/EPROM/Flash ROM Disk		12
2.4	Watchdog Timer		14
CHAPTER 3	3	SVGA SETUP	22
3.1	Introduction		22
3.1.1	Chipset		22
3.1.2	Display Memory		22
3.2	Flat Panel BIOS and Wiring		22
APPENDIX A	A	PIN ASSIGNMENTS	31
	IDE Interface Connector		31
	VGA/Flat Panel Connectors		32
	Flat Panel Connector Pin Assignment		33
	Floppy Disk Connector		34
	Parallel Port Interface		35
	Serial Port Interface		36
	Keyboard and PS/2 Mouse Connector		37
	16-bit General Purpose I/O		37
	PC/104 Connectors		38
Warranty			40

Chapter 0

Startup

0.1 Packing List


Product Name	Function	Package
ICOP-6052VF	Embedded 386SX PC/104 All-in-One CPU Module with onboard CRT/LCD	<ul style="list-style-type: none">● ICOP-6052VF Embedded 386SX PC/104 All-in-One CPU Module● Utility and Drivers Diskette x 1● FDD cable x 1● HDD cable x 1● RS232 cable x 2● Printer cable with bracket x 1● AT KB connector cable x 1● VGA cable x 1

0.2 Specifications

Features	ICOP-6052VF
Chipset	DM&P(ALi) M6117D
Processor	386SX-60 MHz
Multi I/O Chip	ALi 5113
BIOS	AMI BIOS
Watchdog Timer	From 30.5 μ s to 512 seconds
Bus Interface	PC/104 standard compliant
RAM	8MB onboard
DiskOnChip Sockets	1
Display	VGA/LCD
VGA CRT/LCD Chip	TOPRO TP6508IQ
Enhanced IDE Port	1
Floppy Connector	1
Serial Port	RS232 X 2 (or RS232x1,RS485x1)
Parallel Port	1
Power Requirement	+5V @0.6A
Board Weight	90g
Board Size	90mm x 96mm

0.3 Component Location

ICOP-6052VF



Chapter 1

Introduction

1.1 Features

- PC/104 (96x90 mm) Embedded CPU Module
- PC/104 connector
- DM&P (ALi) M6117D Embedded CPU, 100% compatible with 386SX-60 CPU
- 8MB EDO RAM onboard
- Enhanced IDE devices and FDD interface
- One Bi-directional Parallel Port
- RS-232 interface
- RS-232/485 interface
- Watchdog timer
- Socket(s) for Flash or DiskOnChip
- Onboard Keyboard, Mouse header
- Single voltage +5 V power connector
- Operating temperature from $-20 \sim +60^{\circ}\text{C}$
- Flexible OEM/ODM design

1.2 Specifications

- **Embedded CPU:** DM&P(ALi) M6117D is an implementation of an INTEL compatible 386SX-60 CPU, Realtime clock, a watchdog timer and ALi's M1217B chipset
- **BIOS:** Y2K compliant AMI system BIOS
- **DRAM Memory:** 8MB EDO DRAM onboard
- **Bus Interface:** PC/104
- **Data Bus:** 16-bit
- **Bus Speeds:** PC/104 - 8 MHz

(above values are defaults, bus speeds are programmable up to 16 MHz)

- **DMA Channels:** 7
- **Interrupt Levels:** 15
- **Enhanced IDE:** supports one port and up to two hard drives or Enhanced IDE devices of PIO mode 4. BIOS enabled/disabled
- **Watchdog Timer:** generates either a RESET, NMI or an IRQ when your application loses control over the system. Optionally the watchdog can trigger a user specified interrupt. The watchdog is configurable from 30.5 μ s to 512 seconds (in 30.5 μ s segments)
- **Real-time Clock:** included in M6117D with onboard lithium battery backup for data retention. CMOS data backup of BIOS setup and BIOS default.

- **Keyboard and Mouse Connectors:**

Internal 5-pin header for AT-keyboard

Internal 5-pin header for PS/2-mouse

High Speed Multi I/O

- **Chipset:** ALi 5113 or SMS CFDC37C669
- **Serial ports:** one high speed RS-232 port, one high speed RS-232/485 port (jumper selectable). Both with 16C550 UART and 16 byte FIFO. BIOS enabled/ disabled
- **Floppy Disk Drive Interface:** supports up to two floppy drives, 5¼" (360 KB or 1.2 MB) and 3½ " (720 KB, 1.44 MB). BIOS enabled / disabled
- **Bi-directional Parallel Port:** supports SPP, EPP and ECP mode. BIOS

enabled/disabled

Environmental and Power

- **Power Requirements:** single voltage +5 V@600mA
- **Board Dimensions:** 90 (L) x 96 (W) mm.
- **Board Weight:** 90g
- **Extended Operating Temperature:** -20~+60 °C

1.3 VGA Interface

(ICOP-6052VF)

- **Chipset:** TOPRO TP6508IQ
- **Memory:** 1 MB onboard
- **System Bus:** 16-bit ISA bus
- **Panel Data Bus:** 24-bit
- **Display:** CRT and Flat Panel Mono/TFT/DSTN/EL
- **Supported Flat Panels:**

NEC NL-6448AC30-10 TFT 9.4" 640X480

NEC NL-6448AC30-03 TFT 9.4" 640X480

NEC NL-6448AC33-10 TFT 10.4" 640X480

NEC NL-6448AC33-13 TFT 10.4" 640X480

NEC NL-6448AC33-18 TFT 10.4" 640X480

NEC NL-8060BC31-09 TFT 12.1" 800X600

NEC NL-8060AC31-02 TFT 10.4" 800X600

NEC NL-8060AC31-01 TFT 10.4" 800X600

SHARP LQ10D42 TFT 10.4" 640X480

SHARP LQ10D421 TFT 10.4" 640X480

SHARP LQ12531 TFT 12.1" 800x600

SHARP LM64C35P MONO 10.4" 640X480

Planar EL640.480-AA1 EL color 10.4" 640X480

1.4 DiskOnChip 2000 Flash Disk


Flash Disk DiskOnChip ® 2000

- **Package:** Single Chip FlashDisk in 32-pin DIP JEDEC
- **Capacity:** 1-144 MByte capacity
- **Data Reliability:** ECC/EDC error correction
- **Memory Window:** 8 KByte

Chapter 2

Installation

2.1 Jumper Settings



ICOP-6052VF

J1 RESET Switch

J6 Power connector (Reserved):

This 4 pin connector link to the +12V,-12V,-5V and GND pins of PC/104 connector. In case if you need +12,-12V or -5V for external device, you can use this connector. The power should supply by the PC/104 bus.

Pin 1: +12V

Pin 2: -12V

Pin 3: -5V

Pin 4: GND

J10 RS-232/485 selection for COM2

1-2: RS-232 mode

2-3: RS-485 mode

J16 IDE LED Connector

J18 Power Voltage for LCD Usage

1-2: 5V

2-3: 3.3V

J20 IRQ 9 Setting for VGA

Open: Disable

Close: Enable

2.2 Connectors

ICOP-6052VF

J2	Mouse connector
J7	Keyboard connector
J8	Printer port
J9	FDD controller
J11	COM2 RS-485
J12	GPIO (16-bit General Purpose Input Output)
J13	COM 1 RS-232
J14	COM 2 RE-232
J15	IDE connector
J17	CRT SVGA connector
J19	LCD connector

2.3 DiskOnChip/EPROM/Flash ROM Disk

Setup a DiskOnChip ® 2000 Flash Disk

Installation Instructions

1. Make sure the ICOP-605X is powered OFF
2. Plug the DiskOnChip 2000 device(s) into its socket. Verify the direction is correct (pin 1 of the DiskOnChip 2000 is aligned with pin 1 of the socket)
3. Set address for both DiskOnChip and Flash Disk devices as below instructions:

Step1: Enter to AMI BIOS Setup Utility while system power on

Step2: Enter to "Advanced Chipset Setup"

Step3: Select "GPCS Function" to "Enable"

(For DiskOnChip)

Step4: Select "GPCS0 Command" to "MEMR/W 8bit"

Step5: Select "GPCS0 Start Address" to "0C8000 HEX"

Step6: Select "GPCS0 Size" to "8 KBYTE" (goto Step 10)

(For Flash Disk)

Step4: Select "GPCS0 Command" to "MEMR/W 8bit"

Step5: Select "GPCS0 Start Address" to "0E0000 HEX"

Step6: Select "GPCS0 Size" to "64 KBYTE"

Step7: Select "GPCS1 Command" to "IOW 8bit"

Step8: Select "GPCS1 Start Address" to "000100 HEX"

Step9: Select "GPCS1 Size" to "2 BYTE"

Step10: Save changed and exit.

4. Power up the system
5. During power up you may observe the messages displayed by the DiskOnChip 2000 when its drivers are automatically loaded into system's memory
6. At this stage the DiskOnChip 2000 can be accessed as any disk in the system
7. If the DiskOnChip 2000 is the only disk in the system, it will appear as the first disk (drive C: in DOS)
8. If there are more disks besides the DiskOnChip 2000, the DiskOnChip 2000 will appear by default as the last drive, unless it was programmed as first drive. (please refer to the DiskOnChip 2000 utilities user manual)

9. If you want the DiskOnChip 2000 to be bootable: a - copy the operating system files into the DiskOnChip by using the standard DOS command (for example: sys d:) b - The DiskOnChip should be the only disk in the systems or should be configured as the first disk in the system (c:) using the DUPDATE utility

For more information on DiskOnChip2000 technology, visit M-Systems Web site [http:// www.m-sys.com](http://www.m-sys.com) where you can find Utilities Manual, Data Sheets and Application Notes. In addition, you can find the latest DiskOnChip 2000 S/W Utilities.

2.4 Watchdog Timer

The watchdog timer uses a 32.768 KHz frequency source with a 24-bit counter. Its time range stretches from 30.5 ms to 512 sec. with a resolution of 30.5 ms. When the watchdog times out a System RESET, NMI or IRQ can be invoked. Watchdog timer control and the 24-bit counter itself occupy 6 consecutive 8-bit address locations.

When functioning properly the system resets the watchdog timer periodically to prohibit that it times out. If the watchdog timer times out, it will RESET the system, or generate an NMI or IRQ, depending on its configuration.

Watchdog or System Timer

Another great application is to generate a periodic IRQ signal. Under DOS environment, the 8254, system timer 0, will generate IRQ0 every 54.9 ms. The watchdog is like system timer 0. It can be programmed to periodically generate a configurable IRQ. It may be clear that the selected IRQ, will be no longer available to the system.

Configuring the Watchdog Timer in the BIOS

The M6117D watchdog configuration register can be controlled by software or can be setup in the BIOS. To do so go to BIOS Setup's "Advanced Chipset Setup"

Watchdog Function = Enable/Disable

Watchdog Signal = RESET, NMI or IRQ

3/4/5/6/7/9/10/11/12/14/15

Watchdog Timer = 1/2/4/8/16/32/64/128/256/512 Seconds

The BIOS setup only offers a limited amount of time-out values. More a higher resolution of timeout values refer to the next paragraph "Configuring the Watchdog Timer by Software" Note that in case of using the BIOS setup, the watchdog starts counting the moment it passes the BIOS setup. This means that if you set the time-out period to 1 second, the system will keep rebooting before being able to load operating system or software !

After you have finished configuring your watchdog timer read "Timeout Status & Reset - INDEX 3CH" on page 12 and look at the example on page 15 to find out how to periodically reset the timeout status to prevent the watchdog timer from invoking a RESET, NMI or IRQ.

Configuring the Watchdog Timer by Software

Chipset configuration registers

The M6117D configuration register INDEX 37H, 38H, 39H, 3AH, 3BH, 3Ch are used to control the watchdog functions and/or display its current status.

Enable/Disable watchdog - INDEX 37H

Bit	Value	Action
7	reserved	Do not modify the value of these bits!
6	0	Disable watchdog timer
	1	Enable watchdog timer
5-0	Other function	Do not modify the value of these bits!

Watchdog time out action - INDEX 38H

Bit	Value	Action
7-4	0000	No output signal
	0001	IRQ3
	0010	IRQ4
	0011	IRQ5
	0100	IRQ6
	0101	IRQ7
	0110	IRQ9
	0111	IRQ10
	1000	IRQ11
	1001	IRQ12
	1010	IRQ14
	1011	IRQ15
	1100	NMI
	1101	System RESET
	1110	No output signal
	1111	No output signal

3-0	Other function	Do not modify the value of these bits!
-----	----------------	--

Watchdog timer - INDEX 39H, 3AH, 3BH

Index	3Bh	3Ah	39h
Bits	D7.....D0	D7.....D0	D7.....D0
counter	[VSB.....LSB]

For example

Index	3Bh	3Ah	39h	Time out
	00h	00h	01h	30.5µs
	00h	00h	02h	61µs
	00h	01h	00h	7.8 ms
	00h	02h	00h	15.6 ms
	01h	00h	00h	2 s
	02h	00h	00h	4 s
	FFh	FFh	FFh	512 s

Timeout Status & Reset - INDEX 3CH

Bit	Value	Action
7	0	Timeout has not occurred
	1	Timeout has occurred
6	1	Reset timer
	0	Has no meaning
5-0		Other function, do not modify these bits

Programming the watchdog

To perform any operation on the M6117D configuration registers you always

have to unlock first and lock the registers afterwards

Unlock configuration register

Lock configuration register

mov al, 013h	mov al, 013h
out 22h, al	out 22h, al
nop	nop
nop	nop
mov al, 0c5h	mov al, 000h
out 23h, al	out 23h, al
nop	nop
nop	nop

Read the value of a configuration register

For example, read INDEX 3Ch :

Unlock configuration register

```

mov al, 03ch
out 22h, al
nop
nop
in al, 23h
nop
nop
push ax

```

Lock configuration register

```

pop ax ;AL - result

```

Write data to configuration register

For example, write 0FFh to INDEX 3Bh :

Unlock configuration register

```

mov al, 03bh
out 22h, al
nop
nop
mov al, 0ffh

```

```
out 23h, al
nop
nop
```

Lock configuration register

Watchdog Program Example

We use the following sequence to initialize the watchdog timer:

- (1) Unlock configuration register.
- (2) Disable watchdog timer by setting INDEX 37H Bit 6 to '0'.
- (3) Set the expected counter value to INDEX 3BH, 3AH, 39H.
- (4) Select timeout action from INDEX 38H Bit 7-4.
- (5) Enable watchdog timer by setting INDEX 37H Bit 6 to '1'.
- (6) Lock configuration register.

Example: Set timeout to 128 sec to generate a system RESET.

```
; Please use MASM to compiler the following program
; Execute under DOS environment
dosseg
.model small
.stack 100h
.code
main proc
    mov ax, 0c513h ; Unlock config. register
    call writechip
    mov ax, 03737h ; Disable watchdog timer
    call readchip
    and al, 10111111b
    xchg ah, al
    call writechip
    mov ax, 0403bh ; Set the expected counter
```

```

                ; value

call writechip ; to [400000h]
mov ax, 0003ah ; 30.5*sec*400000h= 128 sec
call writechip
mov ax, 00039h
call writechip
mov ax, 03838h ; Select "system reset" as
                ; timeout action

call readchip
and al, 00001111b
or al, 11010000b
xchg ah, al
call writechip
mov ax, 03737h ; Enable watchdog timer
call readchip
or al, 01000000b
xchg ah, al
call writechip
mov ax, 00013h ; Lock config. register
call writechip
mov ax, 04c00h
int 21h
main endp

readchip proc
    out 22h, al
    nop
    nop
    in al, 23h
    nop

```

```

        nop
        ret
readchip endp
writechip proc
        out 22h, al
        nop
        nop
        xchg ah, al
        out 23h, al
        nop
        nop
        xchg ah, al
        ret
writechip endp
end main

```

Reset watchdog timer

Resets the watchdog timer periodically to prevent timeout.

```

        mov ax, 0c513h ; Unlock configuration
                        ; register
        call writechip
        mov ax, 03C3Ch ; Reset watchdog timer
                        ; counter
        call readchip
        or al, 0100 0000 ; The counter is reset at
        xchg ah, al ; out 23h, al
        call writechip
        mov ax, 00013h ; Lock configuration
                        ; register

```



```
call writechip
```

(the above code uses readchip and writechip procedures)

Chapter 3

SVGA Setup

3.1 Introduction

The ICOP-6052VF has an on-board VGA interface. The specifications and features are described as follows:

3.1.1 Chipset

The ICOP-6052VF uses a TOPRO TP65081Q for its SVGA controller, which supports conventional analog CRT monitor or flat panel. In addition, it also supports interlaced and non-interlaced analog monitors (color and monochrome VGA) in high-resolution modes while maintaining complete IBM VGA compatibility. Multiple frequency (multisync) monitors are handled as if they were analog monitors.

3.1.2 Display Memory

With 1 MB memory, the VGA controller can drive CRT displays or color panel displays with resolutions up to 1024 x 768 at 256 colors.

3.2 Flat Panel BIOS and Wiring

Below is a list of optional Flat Panel SVGA BIOS. The VGA BIOS is combined with the system BIOS in a single. To change to another BIOS please contact your local dealer.

MLCD.dat - Data File for MONO DSTN640*480 (**Default**)

- example :
- (1) HOSIDEN HLM6667
 - (2) HITACHI LMG5160XUFC
 - (3) CASIO MD650TS00-01
 - (4) OPTREX DMF_50260NFU-FW-8

DSTN.dat - Data file for Color DSTN640*480

- example :
- (1) Sanyo LCM-5331-22NTK
 - (2) SHARP LM64C35P

TFT_S1.dat - Data File for TFT640*480-Sync (16 BIT)

TFT_S2.dat - Data File for TFT640*480-Sync (18/24 BIT)

- example :
- (1) HITACHI TX26D60/TX24D55
 - (2) TOSHIBA LTM09C015A
 - (3) SHARP LQ10D321

TFT_LP1.dat - Data File For TFT640*480-LP (16 BIT)

TFT_LP2.dat - Data File For TFT640*480-LP (18/24 BIT)

- example :
- (1) Toshiba LTM09c015A)

TFT86_S1.dat - Data File for TFT800*600_sync (16 BIT)

TFT86_S2.dat Data File for TFT800*600_sync (18/24 BIT)

- example :
- (1) NEC NL8060AC26-05
 - (2) NEC NL8060AC26-04
 - (3) NEC NL8060BC31-02

EL.dat - Data File for EL640*480

- example :
- (1) PLANAR EL640.480-A

PLASMA.dat - Data File for PLASMA640*480

- example :
- (1) PANASONIC S817

CRT/Flat Panel Mode

All the above BIOS support either CRT only, Flat Panel only or CRT/Flat Panel simultaneously. To set the mode a Panel Switching Utility is used.

USAGE:

At DOS prompt type >**SW508** then Screen will show

- 1. CRT Only
- 2. Panel Only
- 3. CRT/Panel Simutaneous

NEC NL6448AC33-18 wiring

NEC NL6448AC33-18		ICOP-6052V CON1	
Pin	Pin Name	Pin	Pin Name
CN1-1	GND	3	GND

CN1-2	CLK	35	SHFCLK
CN1-3	Hsync	38	LP
CN1-4	Vsync	36	FLM
CN1-5	GND	4	-
CN1-6	R0	27	P18
CN1-7	R1	28	P19
CN1-8	R2	29	P20
CN1-9	R3	30	P21
CN1-10	R4	31	P22
CN1-11	R5	32	P23
CN1-12	GND	33	-
CN1-13	G0	19	P10
CN1-14	G1	20	P11
CN1-15	G2	21	P12
CN1-16	G3	22	P13
CN1-17	G4	23	P14
CN1-18	G5	24	P15
CN1-19	GND	34	-
CN1-20	B0	11	P2
CN1-21	B1	12	P3
CN1-22	B2	13	P4
CN1-23	B3	14	P5
CN1-24	B4	15	P6
CN1-25	B5	16	P7
CN1-26	GND	39	-
CN1-27	ENAB	37	MDE

CN1-28	Vcc	43	Vcc
CN1-29	Vcc	44	Vcc
CN1-30	NC	-	-
CN1-31	NC	-	-

NEC NL6448AC30-10 wiring

NEC NL6448AC30-10		ICOP-6052V CON1	
Pin	Pin Name	Pin	Pin Name
CN1-1	CLK	42	SHFCLK
CN1-2	Hsync	38	LP
CN1-3	Vsync	36	FLM
CN1-4	DE	37	MDE
CN1-5	-	-	P0
CN1-6	B0	10	P1
CN1-7	B1	11	P2
CN1-8	B2	12	P3
CN1-9	B3	13	P4
CN1-10	-	14	P5
CN1-11	-	15	P6
CN1-12	G0	16	P7
CN1-13	G1	17	P8
CN1-14	G2	18	P9
CN1-15	G3	19	P10
CN1-16	-	20	P11
CN1-17	R0	21	P12
CN1-18	R1	22	P13

CN1-19	R2	23	P14
CN1-20	R3	24	P15
CN1-21	-	-	P16
CN1-22	-	-	P17
CN1-23	-	27	P18
CN1-24	-	28	P19
CN1-25	-	29	P20
CN1-26	-	30	P21
CN1-27	-	31	P22
CN1-28	-	32	P23
CN1-29	PVcc	5	LCD Vdd
CN1-30	Vcc	43	Vcc
CN1-31	MODE	44	Vcc
CN1-32	GND	3	GND
CN1-33	GND	4	GND
CN1-34	Vdd +12	1	+12
CN1-35	ENABKL	40	ENABKL
CN1-36	GND	39	GND

LJ32H028 wiring

LJ32H028		ICOP-6052V CON1	
Pin	Pin Name	Pin	Pin Name
CN1-1	D1	11	P2
CN1-2	D0	12	P3
CN1-3	D3	9	P0
CN1-4	D2	10	P1

CN1-5	CP2	35	SHF_CLK
CN1-6	GND	3,4	GND
CN1-7	CP1	38	LP
CN1-8	GND	33,34	GND
CN1-9	S	36	FLM
CN1-10	-	-	-
CN1-11	-	-	-
CN1-12	-	-	-
CN1-13	+5V	43,44	+5V(Vdd)
CN1-14	-	-	-
CN1-15	+12V	1,2	+12V

SHARP LQ10D42 wiring

(640 X 480 TFT Color)

SHARP LQ10D42		ICOP-6052V CON1	
Pin	Pin Name	Pin	Pin Name
CN1-1	GND	3,4	GND
CN1-2	CLK	42	SHFCLK
CN1-3	Hsync	38	LP
CN1-4	Vsync	36	FLM
CN1-5	GND	3,4	GND
CN1-6	R0	21	P12
CN1-7	R1	22	P13
CN1-8	R2	23	P14
CN1-9	R3	24	P15
CN1-10	R4	25	P16
CN1-11	R5	26	P17

CN1-12	GND	3,4	GND
CN1-13	G0	15	P6
CN1-14	G1	16	P7
CN1-15	G2	17	P8
CN1-16	G3	18	P9
CN1-17	G4	19	P10
CN1-18	G5	20	P11
CN1-19	GND	3,4	GND
CN1-20	B0	9	P0
CN1-21	B1	10	P1
CN1-22	B2	11	P2
CN1-23	B3	12	P3
CN1-24	B4	13	P4
CN1-25	B5	14	P5
CN1-26	GND	3,4	GND
CN1-27	ENAB	40	M
CN1-28	Vcc	43,44	Vcc +5V
CN1-29	Vcc	43,44	Vcc +5V
CN1-30	R/L	-	-
CN1-31	U/D	-	-

SHARP LQ12S31 wiring

(800 X 600 TFT Color)

SHARP LQ12S31		ICOP-6052V CON1	
Pin	Pin Name	Pin	Pin Name

CN1-1	GND	3	GND
CN1-2	CLK	35	SHFCLK
CN1-3	GND	4	GND
CN1-4	Hsync	38	LP
CN1-5	Vsync	36	FLM
CN1-6	GND	8	GND
CN1-7	GND	8	GND
CN1-8	GND	8	GND
CN1-9	R0	27	P18
CN1-10	R1	28	P19
CN1-11	R2	29	P20
CN1-12	GND	8	GND
CN1-13	R3	30	P21
CN1-14	R4	31	P22
CN1-15	R5	32	P23
CN1-16	GND	39	GND
CN1-17	GND	39	GND
CN1-18	GND	39	GND
CN1-19	G0	19	P10
CN1-20	G1	20	P11
CN1-21	G2	21	P12
CN1-22	GND	39	
CN1-23	G3	22	P13
CN1-24	G4	23	P14
CN1-25	G5	24	P15
CN1-26	GND	41	GND
CN1-27	GND	41	GND

CN1-28	GND	41	GND
CN1-29	B0	11	P2
CN1-30	B1	12	P3
CN1-31	B2	13	P4
CN1-32	GND	41	GND
CN1-33	B3	14	P5
CN1-34	B4	15	P6
CN1-35	B5	16	P7
CN1-36	GND	41	GND
CN1-37	ENAR	37	M
CN1-38	TST	-	-
CN1-39	Vcc	43	+5Vcc
CN1-40	Vcc	44	+5Vcc
CN1-41	TST	-	-

Appendix A

Pin Assignments

IDE Interface Connector

Pin	Description	Pin	Description
1	Reset	2	GND
3	Data 7	4	Data 8
5	Data 6	6	Data 9
7	Data 5	8	Data 10
9	Data 4	10	Data 11
11	Data 3	12	Data 12
13	Data 2	14	Data 13
15	Data 1	16	Data 14
17	Data 0	18	Data 15
19	GND	20	N/C
21	N/C	22	GND
23	IOW #	24	GND
25	IOR #	26	GND
27	N/C	28	N/C
29	N/C	30	GND-Default
31	Interrupt	32	IOCS16-Default
33	SA1	34	N/C
35	SA0	36	SA2
37	HDC CS0	38	HDC CSI #
39	N/C	40	GND
41	Vcc	42	Vcc
43	GND	44	N/C

VGA/Flat Panel Connectors

CRT/VGA Connector Pin Assignment

(10 Pin Box Header for PC/104 Module)

Pin	Description	Pin	Description
1	Red	2	GND
3	Green	4	GND
5	Blue	6	GND
7	HSYNC	8	GND
9	VSYNC	10	GND

Flat Panel Connector Pin Assignment

(44 Pin for all ICOP 386 Series)

Pin	Description	Pin	Description
1	+12V	2	+12V
3	GND	4	GND
5	PVcc	6	PVcc
7	ENAVEE	8	ENAVEE
9	P0	10	P1
11	P2	12	P3
13	P4	14	P5
15	P6	16	P7
17	P8	18	P9
19	P10	20	P11
21	P12	22	P13
23	P14	24	P15
25	P16	26	P17
27	P18	28	P19
29	P20	30	P21
31	P22	32	P23
33	GND	34	GND
35	SHFCLK	36	FLM
37	M	38	LP
39	GND	40	ENABKL
41	GND	42	ASHFCLK
43	Vcc	44	Vcc

Floppy Disk Connector



Pin	Description	Pin	Description
1	GND	2	Drive Enable Select
3	GND	4	N/C
5	GND	6	N/C
7	GND	8	Index #
9	GND	10	Drive select 0
11	GND	12	Drive select 1
13	GND	14	Drive select 2
15	GND	16	Motor enable
17	GND	18	Direction #
19	GND	20	STEP #
21	GND	22	Write data #
23	GND	24	Write gate #
25	GND	26	Track 0 #
27	GND	28	Write protect #
29	GND	30	Read data #
31	GND	32	Side 1 select #
33	GND	34	Disk change #

Parallel Port Interface


Pin	Description	Pin	Description
1	Strobe	2	Data 0
3	Data 1	4	Data 2
5	Data 3	6	Data 4
7	Data 5	8	Data 6
9	Data 7	10	Acknowledge #
11	Busy	12	Paper Empty #
13	Printer Select	14	Auto Form Feed #
15	Error #	16	Initialize #
17	Printer Select In #	18	GND
19	GND	20	GND
21	GND	22	GND
23	GND	24	GND
25	GND	26	NC

Serial Port Interface

10- Pin	D-Type	Description
1	1	Data Carrier Detect (DCD)/5V/12V
2	2	Receive Data (RXD)
3	3	Transmit Data (TXD)
4	4	Data Terminal Ready (DTR)
5	5	Ground (GND)
6	6	Data Set Ready (DSR)
7	7	Request to Send (RTS)
8	8	Clear to Send (CTS)
9	9	Ring Indicator (RI)/5V/12V
10	X	NC




Keyboard and PS/2 Mouse Connector



Note for Keyboard:

Pin1: KBCLK

Pin2: KBDATA



Note for Mouse:

Pin1: MCLK

Pin2: MDATA

16-bit General Purpose I/O

Pin	Description	Pin	Description
1	GND	2	Vcc
3	GP0	4	GP8
5	GP1	6	GP9
7	GP2	8	GP10
9	GP3	10	GP11
11	GP4	12	GP12
13	GP5	14	GP13
15	GP6	16	GP14
17	GP7	18	GP15
19	Vcc	20	GND

PC/104 Connectors

64-Pin Long Connector

PIN No.	PIN Name	PIN No.	PIN Name
1	IOCHCHK *	2	0V
3	SD7	4	RESETDRV
5	SD6	6	+5V
7	SD5	8	IRQ9
9	SD4	10	-5V
11	SD3	12	DRQ2
13	SD2	14	-12V
15	SD1	16	ENDXFR *
17	SD0	18	+12V
19	IOCHRDY	20	(KEY)
21	AEN	22	SMEMW *
23	SA19	24	SMEMR *
25	SA18	26	IOW *
27	SA17	28	IOR *
29	SA16	30	DACK3 *
31	SA15	32	DRQ3
33	SA14	34	DACK1 *
35	SA13	36	DRQ1
37	SA12	38	REFRESH *
39	SA11	40	SYSCLK
41	SA10	42	IRQ7
43	SA9	44	IRQ6
45	SA8	46	IRQ5
47	SA7	48	IRQ4
49	SA6	50	IRQ3
51	SA5	52	DACK2 *
53	SA4	54	TC
55	SA3	56	SALE
57	SA2	58	+5V
59	SA1	60	OSC
61	SA0	62	0V
63	0V	64	0V

40-Pin Short Connector

PIN No.	PIN Name	PIN No.	PIN Name
1	0V	2	0V
3	MEMCS16 *	4	SBHE *
5	IOCS16 *	6	LA23
7	IRQ10	8	LA22
9	IRQ11	10	LA21
11	IRQ12	12	LA20
13	IRQ15	14	LA19
15	IRQ14	16	LA18
17	DACK0 *	18	LA17
19	DRQ0	20	MEMR *
21	DACK5 *	22	MEMW *
23	DRQ5	24	SD8
25	DACK6 *	26	SD9
27	DRQ6	28	SD10
29	DACK7 *	30	SD11
31	DRQ7	32	SD12
33	+5V	34	SD13
35	MASTER *	36	SD14
37	0V	38	SD15
39	0V	40	(KEY)

Warranty

This product is warranted to be in good working order for a period of one year from the date of purchase. Should this product fail to be in good working order at any time during this period, we will, at our option, replace or repair it at no additional charge except as set forth in the following terms. This warranty does not apply to products damaged by misuse, modifications, accident or disaster. Vendor assumes no liability for any damages, lost profits, lost savings or any other incidental or consequential damage resulting from the use, misuse of, or inability to use this product. Vendor will not be liable for any claim made by any other related party. Return authorization must be obtained from the vendor before returned merchandise will be accepted. Authorization can be obtained by calling or faxing the vendor and requesting a Return Merchandise Authorization (RMA) number. Returned goods should always be accompanied by a clear problem description.