

RU-87P1/2/4/8

User Manual

Version 1.0

October 9, 2007

Original Writer: Martin Hsu

Last Writer: Janice Hong



Table of Contents

Chapter 1	Introduction	4
1.1	Specifications	7
Chapter 2	Hardware Configuration.....	8
2.1	View of the RU-87PN	8
2.1.1	Preparation	8
2.1.2	Wire the 87Pn to power and PC	9
2.1.3	87Pn's CPU module:	9
2.1.4	RU-87Pn series CPU Module Description	11
2.1.5	Plug in the I/O modules:	11
2.1.6	Wiring the I/O modules:	12
2.1.7	Installing RU-87Pn extension unit.....	15
2.2	Setup the 87Pn system parameter:	16
2.2.1	Communication parameters of 87Pn CPU module:.....	16
Chapter 3	Software Configuration.....	18
3.1	Setup RU-87Pn with DCON Utility.....	18
3.1.1	87Pn Auto Config. Enable:.....	20
3.1.2	87Pn Auto Config. Disable:.....	22
3.2	Save & Load 87Pn Configure file	23
3.2.1	Save the module command to file:	24
3.2.2	Load the Configure file.....	26
3.3	Load & Write configure file	28
3.4	Operating in off-line mode:	30
Chapter 4	Software Development Kits (SDK)	35
4.1	DCON DLL	35
4.1.1	DLL Use Steps	35
4.1.2	VB Example (Reading an analog input value)	37
4.2	DCON ActiveX.....	39
4.2.1	Procedure for using the ActiveX	39
4.2.2	VB Example (Reading an analog input value)	40
4.3	DCON LabVIEW.....	42
4.3.1	Procedure for using DCON_LabVIEW.....	42
4.3.2	LabVIEW Example (Reading multi-channel analog Input value)	44
4.3.3	LabVIEW Demo Program (Reading multi-channel analog input value)	45
4.4	DCON Indusoft	46
4.4.1	Procedure for using the Indusoft bundled driver	46
4.4.2	Indusoft Example (Reading an analog input value)	47
4.5	NAP OPC Server.....	50
4.5.1	Procedure for using the OPC server.....	50
4.5.2	OPC Server Example (Reading an analog input value)	51
Appendix A : Dimension.....	52	
Appendix B : Compare RU-87Pn with i-87Kn	57	
Appendix C : Solution for 87K I/O module on the slot.....	58	
Appendix D : Description For ini Files	62	
Appendix E : Frame Ground	63	
Appendix F : Application of RS-485 Network	64	

FIGURE


Fig.1 : View of 87Pn	8
Fig.2 : Wire the 87Pn to power and PC	9
Fig.3 : 87Pn's CPU module	10
Fig.4 : About CPU module.....	10
Fig.5 : RU-87P4/P8 CPU module description.....	11
Fig.6 : Plug in the I/O structure.....	12
Fig.7 : Internal I/O structure.....	13
Fig.8 : i-87K I/O module Pin assignments	13
Fig.9 : I/O module Wire Connection	14
Fig.10 : I/O module terminal connection.....	14
Fig.11 : Installing RU-87Pn extension unit.....	15
Fig.12 : Setup the address of Rotary Switch on 87P4 CPU module.....	16
Fig.13 : Function description of Dip Switch on 87P4 CPU module.....	17
Fig.14 : Run Dcon Utility and Module Configuration.....	18
Fig.15 : When Auto Config. Enable, incorrect module can't external communication.....	20
Fig.16 : Click "Write to 87Pn" to complete 87Pn module configuration.....	20
Fig.17 : The status after complete the 87Pn module configuration.....	21
Fig.18 : After configuring, you can find out the entire module	21
Fig.19 : How to complete Auto-Configuration for 87Pn.....	22
Fig.20 : When 87Pn Auto Config.: Disable, all the module can external communication	22
Fig. 21 : Click "Configure" to enter the configure screen	24
Fig. 22 : Select and setup the measurement range of module	24
Fig. 23 : Write the settings to RU-87Pn and click "save configuration".....	25
Fig. 24 : Save the configuration file	25
Fig. 25 : Load the settings and check the content of configuration file	26
Fig. 26 : Confirmed the settings, then write to 87Pn CPU module	28
Fig. 27 : Load configuration and write to 87Pn CPU module	29
Fig. 28 : Configure and save file in off-line mode	30
Fig. 29 : Load Configuration and write to 87Pn CPU module in other computer	30
Fig. 30 : Off-line operation.....	31
Fig. 31 : Off-line operation – Configure & Save file	32
Fig. 32 : Load configure file in another PC	33
Fig. 33 : Write the settings to RU-87Pn	34
Fig. 34 : i-87K high/low profile series I/O modules	57
Fig. 35 : The search result between 87Pn and modules	58
Fig. 36 : DCON Utility shows the status of 87Pn expansion slot	58
Fig. 37 : Frame Ground	63
Fig. 38 : Connect to the Earth Ground.....	63

Chapter 1 Introduction

RU-87Pn series is a remote intelligent I/O expansion unit that used to expand i-87K series I/O modules over the RS-485 for industrial monitoring and controlling applications. There are more than 30 I/O modules supported with the unit, including analog input/output, digital input/output, and counter/frequency I/O modules.

RU-87Pn is designed to be used in harsh and noisy environment, so the hardware is manufactured with wide power input range (10~30VDC) and operating temperature (-25°C ~ +75°C). It simplifies installation and maintenance of I/O modules with hot swappable and auto configuration, fault and error detection, dual watchdog, programmable power on and safe values.

Various software development kits (SDK) and demos are provided, such as DLL, ActiveX, Labview driver, Indusoft driver, Linux driver, OPC server, etc. The i-87K series I/O modules plugged in the RU-87Pn can be easily integrated into variant software system.



Features

► Hot Swap

The RU-87Pn doesn't need to shut down its power to replace or plug i-87K I/O modules. Therefore, the whole system can keep operating without any interruption.

► Auto-Configuration

Configurations of i-87K I/O modules can be pre configured and stored in the nonvolatile memory of the RU-87Pn. When the RU-87Pn is power on or an i-87K I/O module is plug in, the RU-87Pn automatically check and restore these configurations to each i-87K I/O modules on it.

► Easy Duplicate System

Using the DCON Utility, you can easily make a backup of the i-87K module configurations and write to another RU-87Pn. This design can easily and quickly duplicate many RU-87Pn

► Easy Maintenance and Diagnostic

The basic configurations (includes station number, baud rate) are set by the rotary and DIP switch. The operator can use only one screwdriver to set the RU-87Pn. And there are several LED status indicators to show whether i-87K modules are configured and work properly.

If one i-87K module is damaged, the operator just need to get one good i-87K module with the same item number to replace the damaged one. And then check the LED indicators to know whether the replacement is performed correctly. The switch and LED design makes it easy for maintenance. There is no PC and Notebook needed.

► Communication

■ RS-485 industrial multi-drop network

The RU-87Pn uses the industrial EIA RS-485 communication to transmit and receive data over long distance (1.2 Km).

■ DCON protocol

i-87K series I/O modules plugged in a RU-87Pn provide a simple command/response protocol (Called DCON protocol) for communication. All command/response are in easy used ASCII format.

► Rugged Industrial Environment

■ Dual watchdog design

The i-87K series I/O modules provides module watchdog and host watchdog. The module watchdog is a hardware watchdog; the host watchdog is a software watchdog. The module watchdog is designed to automatically reset the microprocessor when the module hangs. The host watchdog monitors the host controller (PC or PLC). The output of module can go to the safe value state when the host fails.

■ Programmable power on and safe value

The analog and digital output of modules can be programmed power on and safe value.


■ Wide range power input (10~30 VDC)

Wide range operating temperature (-25 °C ~ +75 °C)

► Fully Software Support

The free charge software utility and development kits include


■ DCON Utility: for configuration



■ OPC Servers:

OPC is an industrial standard interface based on OLE technology. With the OPC server, I/O modules can be easily integrated to any software that has OPC client capability.

■ EZ Data Logger



EZ Data Logger is small data logger software. It can be applied to small remote I/O system. With its user-friendly interface, users can quickly and easily build a data logger software without any programming skill.

■ Support Variant Software Develop Toolkits

The free charge for DLL, ActiveX, Labview driver, Indusoft driver, DasyLab driver, Linux driver.

1.1 Specifications

■ Communication Interface (RS-485)				
Baud rate	115200 bps maximum			
Distance	1.2 Km (4000 ft) maximum			
Isolation	3000 VDC			
■ Switch				
Rotary Switch	*2 , For address			
DIP Switch	8 bit *1, For auto configuration, check sum, baud rate			
■ LED Indicators				
Power	Yes			
System Ready	Yes			
Auto-Configuration	Yes			
Slot Status	Yes			
■ I/O Expansion Slots				
Hot Swap	Yes			
Auto-Configuration	Yes			
Support Module Type : High profile i-87K module only				
Dimensions (W x H x D)				
RU-87P1 (slot x 1)	63.86 x 120.58 x 97.5 mm			
RU-87P2 (slot x 2)	124.60 x 120.58 x 97.5 mm			
RU-87P4 (slot x 4)	230.30 x 120.58 x 97.5 mm			
RU-87P8 (slot x 8)	254.30 x 120.58 x 97.5 mm			
■ Power				
Input Range	10~30 VDC			
Reverse polarity protection	Yes			
Isolation	3000 VDC			
Frame Ground	Yes			
Module	Consumption	Power Board Driving		
RU-87P1	1 W	5 W		
RU-87P2	1 W	8 W		
RU-87P4	2 W	15 W		
RU-87P8	2.4 W	30 W		
■ Environment				
Operating Temperature	-25°C to +75°C			
Storage Temperature	-30°C to +85°C			
Humidity	5 ~ 95%, non-condensing			

Chapter 2 Hardware Configuration

2.1 View of the RU-87PN




Fig.1 : View of 87Pn

2.1.1 Preparation

- ▶ Power Supply: +10V ~ +30V /DC (Ex: DP-665)
http://www.icpdas.com/products/Accessories/power_supply/power_list.htm

- ▶ Converter: RS-232 To RS-485 (Ex: i-7520) or USB to RS-485 (Ex: i-7561)
CD: \ Napdos\7000\Manual\7520.pdf or
http://www.icpdas.com/products/Industrial/communication_module/communication_list.htm

- ▶ Install the DCON Utility to PC (Version 4.5.0 or above version)
CD: \ Napdos\Driver\DCON_Utility or
ftp://ftp.icpdas.com/pub/cd/8000cd/napdos/driver/dcon_utility/

2.1.2 Wire the 87Pn to power and PC

RU-87P4

1. +Vs \Leftrightarrow Power Supply : +Vs (+10~30V) / i-7520 : +Vs
2. GND \Leftrightarrow Power Supply : GND / i-7520 : GND
3. Data+ \Leftrightarrow i-7561/ i-7520 : Data+
4. Data- \Leftrightarrow i-7561/ i-7520 : Data-

i-7561/ i-7520

- ★ 7561's USB port \Leftrightarrow PC's USB port
- ★ i-7520's RS-232 port \Leftrightarrow PC's COM port

P.S. If using i-7520, don't forget to connect the power (+Vs, GND)!



Fig.2 : Wire the 87Pn to power and PC

2.1.3 87Pn's CPU module:

The factory default values are as following table:

Switch	Label	Setting	Description
Rotary Switch (Address)	H	0	Net address = 1 H: High Byte L: Low Byte
	L	1	
Dip Switch (SW1)	Auto Config.	ON	Enable
	Checksum	OFF	Disable
	Baud Rate	ON, ON, ON	115200

Note: The ON of Dip Switch for 87P1 & 87P2 are switching to the **left**, for 87P4 & P8 are to the **right**.

RU-87P1 / RU-87P2 RU-87P4 / RU-87P8





Fig.3 : 87Pn's CPU module



Rotary Switch (Address)

--1~255 (01~FF)
(0: Set as default value)

Dip Switch (SW1)

-- Auto Config (On)
-- Checksum (Off)
-- Baud Rate
(On,On,On,115200)

Module Status LED :

1. Configuring
- *Flashing per 100ms.*
2. Pass
- *Turn off.*
3. Fail
- *Flashing per 2second.*

System LED

- (Red) **PWR LED** :
 1. Power On– Bright.
 2. Power Off– Dark.
- (Green) **S.RDY LED**
 1. Any module configuring
– *Flashing per 100ms*
 2. All of the modules pass the test
– *Bright.*
 3. One or more module test fail
– *Flashing per 2 second.*
- (Green) **Auto Config. LED** :
 1. Auto Config. On – Bright.
 2. Auto Config. Off – Dark.

Fig.4 : About CPU module

2.1.4 RU-87Pn series CPU Module Description

Check the left side of the Power Board for the CPU module LED and Dip Switch description.




Fig.5 : RU-87P4/P8 CPU module description

2.1.5 Plug in the I/O modules:

At present, ICPDAS divides most of the same i-87K I/O module into the Low Profile and High Profile two kinds of version, **if you want to use the module on 87Pn expansion slot, you must choose the High Profile** to assure Auto Config. and Hot Swap function is normal operation.

The related product information about i-87K I/O module is in the CD. You can refer i-87K High Profile series I/O modules in following path:

CD:\Napdos\DCON\IO_Module\87k_modules.htm or to following web-site

ftp://ftp.icpdas.com/pub/cd/8000cd/napdos/dcon/io_module/87k_modules.htm

Example: Plug in i-87019R to Slot 0

p.s. i-87019R is an AI (Analog Input) High Profile module

i-87019R is auto-configured:
Baud Rate: 115200
Checksum: Disable
Net Address: 2





Fig.6 : Plug in the I/O structure



- After plugged in, the slot indicator is flashing per 100 ms.
- When configuration is completed, the LED becomes off.
- If configuration is failed, the LED is always on.

2.1.6 Wiring the I/O modules:

Before wiring the i-87K I/O modules, please check the pin assignment and wiring according to each hardware user manual.

For each i-87K I/O module's hardware user manual please refer to
CD:\Napdos\DCON\IO_Module\87k_modules.htm

According to the internal circuitry diagram and wire connection diagram, please connect the power cable or communication cable to each channel on terminal block of I/O module.




Fig.7 : Internal I/O structure




Fig.8 : i-87K I/O module Pin assignments












Input Type	ON State LED ON Readback as 1	OFF State LED OFF Readback as 0
Relay Contact	Relay ON	Relay Off
		
TTL/CMOS Logic	Voltage < 1V	Voltage > 3.5V
		
NPN Output	Open Collector On	Open Collector Off
		
PNP Output	Open Collector On	Open Collector Off
		
Output Type	ON State LED ON Readback as 1	OFF State LED OFF Readback as 0
Drive Relay	Relay ON	Relay Off
		
Resistance Load		
		

Fig.9 : I/O module Wire Connection





Fig.10 : I/O module terminal connection

2.1.7 Installing RU-87Pn extension unit

Method 1: using the screw to fixed.



Method 2: using the DIN rail clips to fixed.




Fig.11 : Installing RU-87Pn extension unit


2.2 Setup the 87Pn system parameter:

2.2.1 Communication parameters of 87Pn CPU module:

The 87Pns setup its Address, Baud rate and Checksum by adjusting the Dip Switch and Rotary Switch which on 87Pn CPU module. It's not setup by software, please setup the communication condition at first and don't change the communication condition under operating mode.

Step1. Adjusting the Rotary Switch as following diagram, Address is set to the hexadecimal code, divided into High byte and low byte two groups.

Ex: The high byte turns to **0**, the low byte turns to **1** then the address of RS-485 is $16 \times 0 + 1 = 1$;



Ex: The high byte turns to **1**, the low byte turns to **0** then the address of RS-485 is $16 \times 1 + 0 = 16$.



Fig.12 : Setup the address of Rotary Switch on 87P4 CPU module

Note: If you change the address to **00**, no matter where is the actual position of Dip Switch, the system parameter will return to **default value!** (Auto config. On, Checksum off, Baud rate 115200)

Step2. Setup the Dip Switch as following description :




Fig.13 : Function description of Dip Switch on 87P4 CPU module

Note 1: When parameter is changed, 87Pn will auto recharge the internal communication parameters or system parameters, if the external control project is running in the same time, it will cause communication error. Thus don't change communication parameters and system parameter when system is running.

Note 2: if 87Pn's communication parameter has been changed, the external control program must to change the related parameters synchronously.

Step3. Communication parameters of i-87K I/O modules:

The communication parameters of 87K I/O modules are Auto-configured by CPU module.

Rule 1: the Baud Rate & Checksum of the I/O modules on 87Pn expansion slot are always the same as **87Pn CPU module**.
 (Default: Auto Config.: Enable , Baud Rate: 115200 , Checksum: Disable)

Rule 2: the **Net Address** of I/O modules on the slot is based on 87Pn CPU module and increment by 1.
 (Ex. 87Pn CPU module=1, Slot0=2, Slot1=3, Slot2= (empty), Slot3=5....)

If there is no module on slot, the Net Address will be reserved. When the communication parameters of 87Pn CPU module are changed, the parameters of I/O module will be changed with the rules.

Chapter 3 Software Configuration

In this chapter, we will use DCON Utility to complete software configuration of the RU-87Pn, please confirm the hardware equipment has connected and communication parameters of 87Pn CPU module has setup completes. (Please refer to [Chapter 2](#))

- [**3.1 Setup RU-87Pn with DCON Utility**](#)
- [**3.2 Save & Load 87Pn configure file**](#)
- [**3.3 Load & Write configure file**](#)
- [**3.4 Operating in off-line mode**](#)

3.1 Setup RU-87Pn with DCON Utility

At first, please run DCON Utility then click “COM Port” to select COM port and baud rate. You can check your PC’s “Device Manager” to know which COM is connecting. Click “OK” to confirm and escape the screen.





Fig.14 : Run Dcon Utility and Module Configuration

Please click “start search” button to search.




At the first time you can search for “RU-87Pn” only, because the slots of RU-87Pn haven’t completed the configuration. The “[X,X,X,X]” of “Status” means the configuration of that slot is not completed or corrected.

Please click “stop search” to stop the search.



When found RU-87Pn, click to stop search. “[X,X,X,X]” of “Status” means the configuration of that slot is not completed or corrected.

Click “RU-87Pn” to setup slots.



3.1.1 87Pn Auto Config. Enable:

In Fig.12 "Auto Config. ON" expressed that the 87Pn's Auto-Configuration function is "enable", "off" means "disable".

Working Distinction:

If i-87K I/O modules didn't pass the 87Pn correct setup, and install into expansion slot under "Auto Config. Enable" mode, it will regard as incorrect module. For guarantee system's normal operation, the 87Pn will forbid this module external communication. You can't search and configure I/O modules directly by DCON Utility.

The "Auto Config. Enable [X,X,X,X]" in Status column, means the module configuration of that slot is not completed or corrected. Click "RU-87P4" and select "Configure Module" to enter configure screen and know the detail settings about module.




Fig.15 : When Auto Config. Enable, incorrect module can't external communication

In 87Pn configure screen, you can see the scanned module name in "Scanned I/O on Slot" column. Click "Set As Scanned" button to assign module name and click "configure" to setup the I/O module according to the user demand. Finally click "write to 87Pn" for the settings to take effect.




Fig.16 : Click "Write to 87Pn" to complete 87Pn module configuration




Fig.17 : The status after complete the 87Pn module configuration

As above, the i-87K I/O modules on 87Pn expansion slot has configured correctly by "DCON Utility", and then search the module again, you can see the module appear in the search screen. The "Auto Config. Enable [0,0,0,0]" of "Status", means "The I/O configuration of each slot is correct. Each plugged I/O module will be listed under the RU-87Pn.

DCON.Utility_Ver[450] The I/O Modules Found ...						
Module	Address	Baudrate	Checksum	Format	Status	Description
RU-87P4	1[1]	115200	Disable	N,8,1	Auto Config. Enable [0,0,0,0]	4*Slot Auto Configuration Remote Unit(DCON)
-87019R	2[2]	115200	Disable	N,8,1	87P4 Slot[0]	8*AI (Universal mA,mV,V,Thermocouple)(DCON)
-87018R	3[3]	115200	Disable	N,8,1	87P4 Slot[1]	8*AI (mA,mV,V,Thermocouple)(DCON)
-87024	4[4]	115200	Disable	N,8,1	87P4 Slot[2]	4*AO (mA,V)(DCON)
-87055	5[5]	115200	Disable	N,8,1	87P4 Slot[3]	8*DI + 8*DO(DCON)

Fig.18 : After configuring, you can find out the entire module

If the module passed correct configuration, some day when module damage, you don't need to shutdown the power, just remove the damaged module and install the same model number of new module. You needn't configure it again, 87Pn will write the previous settings to the module automatically.




Fig.19 : How to complete Auto-Configuration for 87Pn.

3.1.2 87Pn Auto Config. Disable:

Working Distinction:

In 87Pn Auto Config. Disable mode, allow the i-87K I/O modules of expansion slot to external communications. Therefore, when you perform searching by DCON Utility, you could find 87Pn CPU module as well as 87K I/O modules on the expansion slot.

DCON.Utility_Ver[450] The I/O Modules Found ...						
Module	Address	Baudrate	Checksum	Format	Status	Description
RU-87P4	1[1]	115200	Disable	N,8,1	Auto Config. Disable [0,0,0,0]	4"Slot Auto Configuration Remote Unit(DCON)
-87019R	2[2]	115200	Disable	N,8,1	87P4 Slot[0]	8"AI (Universal mA,mV,V,Thermocouple)(DCON)
-87018R	3[3]	115200	Disable	N,8,1	87P4 Slot[1]	8"AI (mA,mV,V,Thermocouple)(DCON)
-87024	4[4]	115200	Disable	N,8,1	87P4 Slot[2]	4"AO (mA,V)(DCON)
-87055	5[5]	115200	Disable	N,8,1	87P4 Slot[3]	8"DI + 8"DO(DCON)

Fig.20 : When 87Pn Auto Config.: Disable, all the module can external communication

In 87Pn “Auto Config. Disable”, indicate your hardware device is under “disable” mode. You can't make any configuration under this mode. the communication parameters of i-87K I/O module which on expansion slot can't configured by user, it must Auto-Configure by 87Pn, the other usage is the same as the module insert into i-87K4/5/8/9 expansion unit.

In 87Pn “Auto- Config. Disable” mode, doesn't support Auto-Configuration. When module damage, and replace another same model number the module directly, because of their settings (e.g. Type code) may be different, thus can't ensure its normal working. The user must use DCON Utility to re-configure based on the setting value, and replies the normal operation.

Note : In DCON Utility search screen, the message in status column of 87Pn

The meaning of “ Auto Config. Enable [0,X,0,0] “ as following description: :

0 : Means the module configuration on this slot is successful or have no module.

X : Means the module configuration on this slot is uncorrected.

If the status column of 87Pn shows “**Auto Config. Enable [0,0,0,0]**”, means the “Auto Config.” of Dip Switch is switching to the “On”, and the I/O configuration of each slot is correct or has no module.

If the status column of 87Pn shows “**Auto Config. Disable [0,0,0,0]**”, means the “Auto Config.” of Dip Switch is switching to the “Off”, and the I/O configuration of each slot can initialization success or have no module.

3.2 Save & Load 87Pn Configure file

When using 87P operation screen of DCON Utility to configure the i-87K I/O module, DCON Utility will automatically save the necessary information under the installing path “config\”, the file recording some information of related module that will be saved in 87pn, when save as new file, it can be use for system recover and system backup. The related format and detail about configure file, please refer to Appendix A. Here, just description how to save the file as oneself needs and how to load from files.

Note1: When user open the operation interface of 87Pn, if there is the same file in default path will be deleted.

Note2: Using ”Configure” and ”Write To 87Pn” functions in 87Pn operation screen of DCON Utility will automatically save the related data of module of each slot as filename of fixed format and the same path, if user want to use the file as system recover, system backup or remote support, the best way is save the default file as another name to avoid the file been deleted when next time you open the operation interface of 87Pn.

3.2.1 Save the module command to file:

When all modules has configured properly according to the requirement, because each time entered the configuration screen will delete the default file and re-build, so suggestion to save the settings as another files, if the settings is carelessly changed or need to duplicate the same content of config, can load in the config file and write in 87Pn CPU module through operation screen of DCON Utility.

The operation steps is very easy, using "Configure" to setup each I/O module and write the settings to 87Pn, then click "Save Configuration" button and input the description or notes for this configuration file. Finally, input the file name of this project to complete. Please refer to the description as following diagram.




Fig. 21 : Click "Configure" to enter the configure screen




Fig. 22 : Select and setup the measurement range of module




Fig. 23 : Write the settings to RU-87Pn and click “save configuration”




Fig. 24 : Save the configuration file

3.2.2 Load the Configure file

When necessary, you can load the prior configuration file through operation interface of 87pn. This function not only load configuration file, but also load the configuration screen of each module through "Configure" command, using familiar operation screen to check whether the settings is correct. please refer to Fig.24 for description of operating process.






Fig. 25 : Load the settings and check the content of configuration file

Load configuration and confirm the contents of each module, click "Write To 87P4" write the

configuration to 87Pn CPU module.







Fig. 26 : Confirmed the settings, then write to 87Pn CPU module

3.3 Load & Write configure file

If you sure the contents of configure files is what you need, you can load the configuration and write to 87Pn at the same time. As following diagrams, this function is useful for a lot of copy to other 87Pn (as Fig.26).








Fig. 27 : Load configuration and write to 87Pn CPU module

3.4 Operating in off-line mode:

The operation in off-line mode means the computer which operate Docn Utility without connect any module of 87Pn, Using Docn Utility to generated and edit the module command for 87Pn requirement, and then write the command file to another computer which connected with 87Pn , this usage is convenient for remote support or system backup. The contents as following Fig.27 、Fig.28.



To Configure 87Pn Offline

Save Configuration


[SYSTEM]
UNIT=87P4

[COMMENTS]
Date Time=2007/9/11 下午 03:56:30
Description=
Write Description For Configuration File

[Slot0 Comments]
ID=87019R
Firmware=B201h
MODULE_CONFIG=

To Generate Configured file

Fig. 28 : Configure and save file in off-line mode



On the other site, DCON Utility loads the configured file and writes to 87Pn directly.

[SYSTEM]
UNIT=87P4

[COMMENTS]
Date Time=2007/9/11 下午 03:56:30
Description=
Write Description For Configuration File

[Slot0 Comments]
ID=87019R
Firmware=B201h
MODULE_CONFIG=

Load Configuration And Write To 87PX

87P4 Hot Swap and Auto Configuration
I/O Write To 87P4 Addr.[Hex] Slot Configuration Status Set As Scanned Write To 87P4
0 87019R 02 [00H] OK Copy Configure
1 87018R 03 [00H] OK Copy Configure
2 87024 04 [00H] OK Copy Configure
3 87055 05 [00H] OK Copy Configure
4 - - - Copy Configure
5 - - - Copy Configure
6 - - - Copy Configure
7 - - - Copy Configure



Save Configuration Load Configuration Load Configuration And Write To 87PX Help Exit

Scanned I/O on Slot
87019R
87018R
87024
87055

Slot 0 OK !
Slot 1 OK !
Slot 2 OK !
Slot 3 OK !

Fig. 29 : Load Configuration and write to 87Pn CPU module in other computer

Step1 : Select the Module ID, Address, Baudrate and Checksum.



87P4 Hot Swap and Auto Configuration				Scanned I/O on Slot-		
I/O Write To 87P4 Addr.[Hex]		Slot Configuration Status	Set As Scanned		Write To 87P4	Scanned I/O on Slot-
0	02	Empty	<input type="button" value="Copy"/>	<input type="button" value="Configure"/>		
1	03	Empty	<input type="button" value="Copy"/>	<input type="button" value="Configure"/>		
2	04	Empty	<input type="button" value="Copy"/>	<input type="button" value="Configure"/>		
3	05	Empty	<input type="button" value="Copy"/>	<input type="button" value="Configure"/>		
4	-	-	<input type="button" value="Copy"/>	<input type="button" value="Configure"/>	-	
5	-	-	<input type="button" value="Copy"/>	<input type="button" value="Configure"/>	-	
6	-	-	<input type="button" value="Copy"/>	<input type="button" value="Configure"/>	-	
7	-	-	<input type="button" value="Copy"/>	<input type="button" value="Configure"/>	-	

<input type="button" value="Save Configuration"/>	<input type="button" value="Load Configuration"/>	<input type="button" value="Load Configuration And Write To 87PX"/>	<input type="button" value="Help"/>	<input type="button" value="Exit"/>
---	---	---	-------------------------------------	-------------------------------------

Fig. 30 : Off-line operation

Step2 : Select and configure the I/O module, then save the settings as another file name, or else next time when you open the 87Pn screen, the previous settings will be deleted.





Fig. 31 : Off-line operation – Configure & Save file



Note: The configure file will be save to C:\ICPDAS\DCON.Utility\for_users

Step3 : Open DCON Utility in another computer which has connected with 87Pn, load the settings into DCON Utility and you can press "Configure" button to check the settings has written to 87Pn correctly. Follow the steps , you can complete the function of Auto-Configuration. also can write to 87Pn directly after loading configuration. as following diagram:






Fig. 32 : Load configure file in another PC





Configure only for auto configuration !





Fig. 33 : Write the settings to RU-87Pn

Chapter 4 Software Development Kits (SDK)

The ICPDAS provides a series of free software development kits, enables the customer to be fast and simply completes the system setup . Related software tools are in the CD, please refer to following diagram:



4.1 DCON DLL

DCON DLL provide program developers to read the program interface which used on control I/O modules, the position of CD place provides a few basic and simple examples, user can understand how to read the control I/O module through the DLL in following examples:

4.1.1 DLL Use Steps

Step 1: Read the basic and important documents


Readme.txt: contains most basic and important information, including:

- What is DCON DLL
- What files are installed on the PC
- The directory tree installed on the PC
- Demo list

Step 2: Install the DCON DLL by executing:

- CD:\Napdos\Driver\DCON_DLL_New\Setup\setup.exe

After installation, all related information can be found below



Step 3 : Read manuals for how to start

QuickStartManual.pdf:

Explains how to develop your first program using the DLL.

DCON_DLL.pdf explains the following details

- How to include the DLL in VB/VC/Delphi/BCB
- How to develop a program in VB/VC/Delphi/BCB
- Demo list
- Function descriptions and usage

FAQ.pdf:

Gives solutions to frequently asked questions.

Step 4 : Run the demo programs to test the I/O module and learn the functions


4.1.2 VB Example (Reading an analog input value)

The following is an example of reading analog values from an i-87017 inserted in slot 0 of an 8410/8810.


Step 1: Run the DCON Utility to configure the I/O modules

Step 2: Run VB and create a new project (.exe project)

Step 3: Add I7000.bas to the project



Step4: Arrange all the components on the form



Step5: Write the program code

```

Private Sub cmdOpen_Click()
    iPort = 5                      'Use COM Port = 5
    lBaudrate = 115200              'Use Baud Rate = 115200
    Open_Com 5, 115200, 8, 0, 0    'To Open COM Port

    End Sub

Private Sub cmdRead_Click()
    Dim iRet As Integer
    Dim iVal As Integer
    Dim fVal As Single
    Dim iSlot As Integer
    Dim iTotals As Integer
    Dim iCh As Integer
    Dim iAddress As Integer
    Dim iFormat As Integer

    iAddress = 3                    'Module Address = 3
    iCheckSum = 0                   'CheckSum Disable
    iTimeOut = 300                  'Timeout For Response
    iSlot = -1                      'Don't Need to Assign Slot For 87K I/O
    iCh = 0                         'Read Channel 0 AI Value
    iTotals = 8                      'Total Channel Of AI Module
    iFormat = 0


    iRet = DCON_Read_AI(iPort, iAddress, iSlot, iCh, iTotals, _
        iCheckSum, iTimeOut, iFormat, fVal, iVal)

    If iRet = 0 Then
        txtRead.Text = Str(fVal)      'The Queried AI Value
    Else
        txtRead.Text = "Error" + Str(iRet)
    End If
End Sub


Private Sub cmdClose_Click()
    Close_Com (5)                  'To Close COM Port
End Sub

```

Step 6: Run the project.



4.2 DCON ActiveX



DCON ActiveX

ActiveX (ocx) component

Supported module:

i-7000/8000/87K series
(with DCON protocol)

Supported demos:

VB/VC/BCB/Delphi

Supported OS:

Windows 98/NT/2K/XP

File Location:

CD:\Napdos\Driver\DCON_ActiveX

4.2.1 Procedure for using the ActiveX

Step 1: Read the basic and important documents

Readme.txt: contains most basic and important information, including:

- What is DCON ActiveX
- What files are installed on the PC
- The directory tree installed on the PC
- Demo list


WhatsNew.txt: contains most basic and important information, including:

- Bugs fixed
- Demos added or modified
- Updated ActiveX (ocx) details

Step 2: Install the DCON DLL by executing:

- CD:\Napdos\Driver\DCON_ActiveX_New\Setup\setup.exe

After installation, all related information can be found below



Step 3: Read manuals for how to start.

InstallOCX.pdf:

Explains how to install/uninstall the ActiveX (ocx) component in VB/VC/Delphi/BCB

DCON_ActiveX.pdf explains the following details:

- How to include the ActiveX(ocx) in VB/VC/Delphi/BCB
- How to develop a program in VB/VC/Delphi/BCB
- Demo list
- Function descriptions and usage

Step 4: Run the demo programs to test the I/O module and learn the functions



4.2.2 VB Example (Reading an analog input value)

The following is an example of reading analog values from an i-87017 inserted in slot 0 of an 8410/8810.


Step 1: Run the DCON Utility to configure the I/O module

Step 2: Run VB and create a new project (.exe project)

Step 3: Add the ActiveX (ocx) component to the project



Step 4 : Arrange all the components on the form



Step 5: Write the program code

```

VB Step 2 } Private Sub CmdOpenCom_Click()
             DCONPC_X1.ComPort = 5
             DCONPC_X1.Baudrate = 115200
             DCONPC_X1.PortOpen = True
             End Sub

             'Use COM Port = 5
             'Use Baud Rate = 115200
             'True To Open COM Port

             Private Sub Read_AI_Click()
             Dim AIVal As Single
             Dim AIVal_Hex As Integer, iDataformat As Integer

             DCONPC_X1.ComPort = 5
             DCONPC_X1.Address = 1
             DCONPC_X1.SlotNo = -1
             DCONPC_X1.AITotalChannel = 8
             DCONPC_X1.Checksum = False
             DCONPC_X1.Timeout = 300
             iDataformat = 0
             AIVal = DCONPC_X1.AnalogIn(0)
             TextReadAI.Text = AIVal
             'Use COM Port = 5
             'Module Address = 1
             'Don't Need to Assign Slot For 87K I/O
             'Total Channel Of AI Module
             'Checksum Disable
             'Timeout For Response
             '0: Use Engineering Format
             'Read Channel 0 AI Value

             If DCONPC_X1.ErrorCode <> 0 Then
             Exit Sub
             End If
             End Sub


VB Step 3 }             End Sub

             Private Sub CmdCloseCom_Click()
             DCONPC_X1.PortOpen = False
             'False To Close COM Port
             End Sub


             Private Sub DCONPC_X1_OnError(ByVal lErrorCode As Long)
             MsgBox "Error Code: " + Str(lErrorCode) + Chr(13) _
                   + "Error Message: " + DCONPC_X1.ErrorString
             End Sub

VB Step 1 } 
```

Step 6: Run the Project



4.3 DCON LabVIEW



DCON LabVIEW

Bundled driver for LabVIEW

Supported module:

i-7000/8000/87K Series
(With DCON Protocol)

Supported OS:

Windows 98/NT/2K/XP

File Location:


CD: \Napdos\Driver\DCON_Labview


4.3.1 Procedure for using DCON_LabVIEW

Step 1 : Install the DCON LabVIEW by executing:

- CD:\Napdos\Driver\ DCON_Labview\ DCON_Labview.exe

After installation, the related information can be found as below:





8000 Demo: Demo programs for i-8000 I/O modules.


8000.llb: LabVIEW library contains all sub-vi for i-8000 I/O modules

CallDLLinLabVIEW.pdf: Explains how to call a sub-vi of in LabVIEW.

DCON_DLL.pdf: Descriptions of all sub-function in DCON_DLL.


Step 2: Create a new LabVIEW program. Refer the DCON_DLL.pdf about detail description of the sub-vi and where to select the sub-vi in various library of DCON_LabVIEW.

Step3: Select the sub-vi form Functions Palette >> Select a VI...




4.3.2 LabVIEW Example (Reading multi-channel analog Input value)


Step4 : Select the target *.lib file (LabVIEW library file)



Step5 : Select the desired sub-vi



Step6 : Put the icon of selected sub-vi on Block Diagram, refer the “Help” >> “Show Help” or “[DCON_DLL.pdf](#)” in step1 for detail.




Step7 : Draw the data flow of sub-vi.


4.3.3 LabVIEW Demo Program (Reading multi-channel analog input value)

Step 1: Select the appropriate demo program (ex. AnalogInAll.vi) by the name according with module's function (ex. i-8017 / AI).

Step2: Set the parameters




You could also refer the "Help">>>"Show Context Help" for getting the simple description of those parameters.



Step3 : Run the Demo.

4.4 DCON Indusoft



DCON Indusoft

Bundled driver for Indusoft

Supported module:

i-7000/8000/87K Series
(With DCON Protocol)

Supported OS:

Windows 98/NT/2K/XP/CE

File Location:

CD: \Napdos\Driver\DCON_Indusoft

4.4.1 Procedure for using the Indusoft bundled driver

Step 1: Read the basic and important documents

Readme.txt: contains the basic and important information, including:

- Files on the shipped CD

Reversion.txt: contains the reversion information, including

- Bugs fixed
- New modules supported

Step 2: Install the Indusoft bundled driver by executing

- CD:\Napdos\Driver\DCON_Indusoft\Setup\setup.exe

Step 3: Read the manuals describing how to start

- The DCON.pdf user's manual describes how to use the Indusoft bundled driver

Step 4: Run the demo programs (ICPDriverTest.zip) to test I/O modules and learn the functions


4.4.2 Indusoft Example (Reading an analog input value)

The following is an example of reading analog values from an i-87018 inserted in slot 0 of an 8410/8810.


Step 1: Run the DCON Utility to configure the I/O modules

Step 2: Run Indusoft and create a new project

Step 3: Include the DCON driver




Step 4: 設定 DCON 驅動程式




Step 5 : Insert tags to connect to I/O modules


The address format is [Address : Module ID : Slot : Channel]



Step6 : Arrange all the components on the form



Step7: Double click the text box to assign a tag to it.



Step8 : Run the project



4.5 NAP OPC Server



NAP OPC server

OPC Server

Supported Module:

i-7000/8000/87K Series

(With DCON Protocol)

Modbus embedded controller

ISaGRAF embedded controller

Supported OS:

Windows 98/NT/2K/XP/CE

File Location:

CD:\Napdos\NapOPCSvr

OPC (OLE for Process Control) is the first standard resulting from the collaboration of a number of leading worldwide automation suppliers working in cooperation with Microsoft. Originally based on Microsoft's OLE COM (component object model) and DCOM (distributed component object model) technologies, the specification defined a standard set of objects, interfaces and methods for use in process control and manufacturing automation applications to facilitate interoperability. The COM/DCOM technologies provided the framework for software products to be developed. There are now hundreds of OPC Data.

4.5.1 Procedure for using the OPC server

Step 1: Read the basic and important documents

Readme.txt: contains the basic and important information, including

- Files on the shipped CD

Reversion.txt: contains the reversion information, including

- Bugs fixed
- New modules supported

Step 2: Install the OPC server by executing

- CD:\Napdos\NapOPCSvr\NapOPCServer.exe

Note: If there is an older version of Nap OPC Server installed on the PC, It must be uninstalled before installing the new version.

Step 3: Read the manuals describing how to start


- The **NapOPCSvr.pdf** is the user's manual describing how to use the OPC server

4.5.2 OPC Server Example (Reading an analog input value)

The following is an example of reading analog values from an i-87018 inserted in slot 0 of an 8410/8810.

Step 1: Run the DCON Utility to configure the I/O modules

Step 2: Run the OPC server to search for I/O modules on COM1



Step 3: Save the configuration and close the OPC Server

Step 4: Run SCADA software to connect to the OPC Server



The OPC Server user's manual lists the procedures for the following SCADA software:

<input checked="" type="checkbox"/> Labview	<input checked="" type="checkbox"/> National	<input checked="" type="checkbox"/> WIZCON
<input checked="" type="checkbox"/> iFix	<input checked="" type="checkbox"/> Indusoft	<input checked="" type="checkbox"/> Citect


Please refer to "Chapter 4 Connecting to the OPC Server" for more details.

Appendix A : Dimension


A.1 – RU-87P1




A.2 – RU-87P2




A.3 – RU-87P4




Top View




Front View




Left Side View



Right Side View




Bottom View



Unit: mm

Back View

A.4 – RU-87P8



Appendix B : Compare RU-87Pn with i-87Kn

Note: i-87K I/O module has divides into the high profile (new version) and the low profile (old version) two kinds, only i-87K high profile series I/O modules can support Hot Swap and Auto-Configuration function correctly.

RU-87Pn & i-87Kn I/O unit comparison

Supported	RU-87Pn with Auto Config. Enable	RU-87Pn with Auto Config. Disable	i-87Kn
i-87K Low Profile module	--	--	😊
i-87K High Profile module	😊	😊	😊
i-87K module Hot Swap	😊	😊	--
Auto- Communication parameter Setup	😊	😊	--
Auto-Configuration	😊	--	--




Fig. 34 : i-87K high/low profile series I/O modules

Please refer to web page :

http://www.icpdas.com/products/PAC/i-8000/8000_IO_modules.htm

Appendix C : Solution for 87K I/O module on the slot

When insert the module on the expansion slot of 87Pn, the same time 87Pn CPU will detect the module name and respond the status of interacting between 87Pn and module. As following diagram, the search result only find out the RU-87P4 and a 87019R which on slot 0, the Status column shows Auto Config. Enable [0,0,X,X]




Fig. 35 : The search result between 87Pn and modules

Click the name “RU-87P4” entering the operation screen to know the settings of 87Pn and the status detected by 87Pn CPU, the module status code in "Slot Configuration Slot" column means the different error message.




Fig. 36 : DCON Utility shows the status of 87Pn expansion slot

As following table, you can accord the error code and LED lamp status to find out the problem solution.

Table 1 : The Error Code in Auto Config. Enable mode

Error Code	Slot LED (Red)	Status	Description	Solution
00H	Dark (ok)	OK	OK	None
01H	Flashing (Warning)	Module scanned in Empty Slot	1. There is a module scanned in this empty setting slot.	1. Remove the module
			2. The first time to setup, no initial value.	Reconfigure it with DCON Utility. 1. Click "Set As Scanned" button and configure module again 2. Click "Write To 87Pn" button to write settings to 87Pn.
02H	Flashing (Warning)	Commands not comparable	Configure failure: This is a 87K I/O module firmware compatibility problem. Some commands at this slot might be too new for this old firmware of 87K I/O module, but it is not serious for system operation.	1. Check the i-87K I/O module's firmware. * Run Dcon Utility→Terminal→Dcon command Line→setup Baud Rate→Command: \$AAF (EX. 01F) →Send * You can see the version, Respond=! 01A1.9 2. Update the 87K I/O module with a new firmware version.
03H	Bright (Error)	Configuration Failed	Configure failure: Some commands are not supported by this 87K I/O module and this error will be serious for system operation.	1. Check the 87K I/O module firmware 2. Update the 87K I/O module with a new firmware version.
04H	Bright (Error)	wrong Configuration format	Configure failure: The format of configured commands is wrong for DCON Protocol.	1. Run DCON Utility. 2. Click the "Write To 87Pn" button to write the settings to 87Pn CPU again.
05H	Bright	Read	The memory data is failed:	1. Run DCON Utility.

	(Error)	Configuration failed	The configured commands are wrong for DCON Protocol.	2. Click the "Write To 87Pn" button to write the settings to 87Pn CPU again.
06H	Bright (Error)	Can not find module	The configured module at this slot has been removed. It is empty now.	1. Please insert a correct module as previous configured one. 2. Or configure with DCON Utility as "Empty" and click the "Write To 87Pn" button to write the configuration to 87Pn CPU.
07H	Bright (Error)	Incorrect module name	Configure failure: The module inserted in this slot is not the same as previous configured.	The insert & configure module name are different, insert the correct one or run the Dcon Utility to modify the settings accord with the module name.
08H	Bright (Error)	Internal INIT* pin failed	Configure failure: The INIT Pin is failed to connect with the GND and module failed to initialize.	1. Please restart the power to initialize to I/O module 2. If it still failed to initialize, send it back to factory to check. Note: RU-87Pn only supports high profile 87K I/O modules.
09H	Bright (Error)	Module address over 255 (FFh)	The module address is over 255 (FFh).	The maximum address of 87P1 is 254 (FEh) 87P2 is 253 (FDh) 87P4 is 251 (FBh) 87P8 is 247 (F7h)
0AH	Bright (Error)	The command count saved to 87Pn is not the same as DCON Utility	This error might be caused by following reasons. 1. Command length error. 2. Command checksum error. 3. Communication error during the process of writing commands to 87Pn.	Please configure this 87K I/O module with DCON Utility, and click the "Write To 87Pn" button to write the configuration to 87Pn CPU again.

Table 2 : The Error Code in Auto Config. Disable mode

Error Code	Slot LED (Red)	Status	Description	Solution
80H	Dark (ok)	Initialize ok	setup success	None
81H	Bright (Error)	Internal INIT* pin failed	The INIT Pin is failed to connect with the GND and module failed to initialize.	If it still fails after restart the 87Pn many times, please send the 87K I/O module back to factory to check.
82H	Bright (Error)	Module address over 255 (FFh)	The module address is over 255 (FFh).	The maximum address of 87P1 is 254 (FEh) 87P2 is 253 (FDh) 87P4 is 251 (FBh) 87P8 is 247 (F7h)

You can see the LED signals on 87Pn CPU module to know whether the 87Pn is operating properly. Please refer to appendix.


	Auto Config. LED (Green)	S.RDY LED (Green)	Slot Status LED (Red)
Auto Config. Enable			
No Error	Always ON	Always ON	Always OFF
Warning		Always ON	Flash
Failed		Flash	Always ON
Auto Config. Disable			
No Error	Always OFF	Always ON	Always OFF
Failed		Flash	Always ON

Appendix D : Description For ini Files

While you save the configuration file, the DCON Utility will save as .ini file. The default path of file as below :

C:\ICPDAS\DCON.Utility\for_users

The INI file explains as follows:



Appendix E : Frame Ground

Electronic circuits are constantly vulnerable to Electro-Static Discharge (ESD), which become worse in a continental climate area. Some I-7000, M-7000 and I-8000 series modules feature a new design for the frame ground, which provides a path for bypassing ESD, allowing enhanced static protection (ESD) capability and ensures that the module is more reliable.

The following options will provide a better protection for the module:

The RU-87Pn controller has a metallic board attached to the back of the plastic basket as shown in the Figure 2-1 below. When mounted to the DIN rail, connect the DIN rail to the earth ground because the DIN rail is in contact with the upper frame ground as shown in the Figure 2-2 below




Fig. 37 : Frame Ground





Fig. 38 : Connect to the Earth Ground

Appendix F : Application of RS-485 Network

The RS-485 length can be up to 4000 ft or 1.2 km over a single set of twisted –pair cables, if the RS-485 network is over 4000 ft or 1.2Km, the RS-485 repeater must be added to extend the RS-485 network.


F.1: Basic RS-485 network

The basic component of the RS-485 network consist of a Master Controller (or using a PC as Host controller), and some RS-485 devices.




F.2: Daisy chain RS-485 network

All RS-485 devices are wired directly to the main wire, If the network is up to 1.2 Km, it will need a repeater (i-7510) to extend the network.




F.3: Star type RS-485 network

There are branches along the main wire. In this case, it is better to have a repeater to isolate or filter the noise that is made by devices.



There is a better choice to use 7513 as a RS-485 hub on start type network.



F.4: Random RS-485 network

